

Service Manual

Stereo Radio Cassette Player

Mini Cassette
RQ-V500

Color

(K)...Black Type

Area

Country Code	Area	Color
(E)	Continental Europe.	(K)
(EG)	F.R. Germany & Italy.	
(GC)	Saudi Arabia.	
(GN)	Oceania.	

- Please file and use this manual together with the service manual for model No. RQ-V500 order No. AD9001010C1.
- This service manual indicates the main differences between; Original RQ-V500 (P).
- Refer to the Schematic Diagram and Circuit Board and Wiring Connection Diagram of this Service Manual.

CHANGES

SPECIFICATIONS

RQ-V500 (P)

General:

Output: Headphones; 20Ω, φ3.5

Radio Section:

Radio Frequency Range: FM; 87.5~108MHz

AM; 520~1710kHz

Intermediate Frequency: FM; 10.7MHz

AM; 450kHz

RQ-V500 (E, EG, GC, GN)

General:

Output: Headphones; 16Ω, φ3.5 (GC, GN)

Radio Section:

Radio Frequency Range: FM; 87.5~108MHz

AM; 531~1602kHz (9kHz Step)

530~1600kHz (10kHz Step)

(GC)


522~1629kHz (E, EG, GN)

Intermediate Frequency: FM; 10.7MHz

AM; 450kHz (GC)

459kHz (E, EG, GN)

LOCATION OF CONTROLS (on page 2)



PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM (on page 5)

•How to remove the plunger

1. Follow the procedures in Ref. Nos. 1~4 in the Disassembly Instructions. (See pages 6, 7.)
2. Remove one screw (1). (See Fig. 7.)
3. Remove the washer and lever in order to remove the plunger. (See Fig. 8.)




Fig. 7




Fig. 8

Panasonic

Matsushita Electric Industrial Co., Ltd.
Central P.O. Box 288, Osaka 530-91, Japan

MEASUREMENTS AND ADJUSTMENTS (on page 11)

• AM ADJUSTMENT

BAND	SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT POINT	REMARKS
	CONNECTIONS	FREQUENCY				
AM-RF ADJUSTMENT						
AM	Fashion loop of several turns of wire and radiate signal into loop of receiver.	600kHz	Tune to signal.	Headphones jack (20Ω) (Refer to Fig. 1)	(* 1) L2 (AM ANT Coil)	Adjust for maximum output. Adjust L2 by moving coil bobbin along ferrite core.
AM		1,500kHz			CT1 (AM ANT Trimmer)	Adjust for maximum output.
(*1) Cement antenna bobbin with wax after completing alignment.						

RQ-V500 (P)

(*1) Cement antenna bobbin with wax after completing alignment.




For (GC, GN) areas

AM	Fashion loop of several turns of wire and radiate signal into loop of receiver.	594kHz	Tune to signal.	Headphones jack (16Ω) (Refer to Fig. 1)	(* 1) L2 (AM ANT Coil)	Adjust for maximum output. Adjust L2 by moving coil bobbin along ferrite core.
AM		1,404kHz			CT1 (AM ANT Trimmer)	Adjust for maximum output.

RQ-V500
(E, EG, GC, GN)


(*1) Cement antenna bobbin with wax after completing alignment.

REPLACEMENT PARTS LIST


Ref. No.	Change of Part No.		Part Name & Description	Remarks
	RQ-V500 (P)	 RQ-V500 (E, EG, GC, GN)		
TRANSISTOR (S)				
Q514	————	2SB1218STW	TRANSISTOR	(GC) Addition
DIODE (S)				
D504	————	MA110TW	DIODE	(GC) Addition
D505	————	MA110TW	DIODE	(E, EG, GN) Addition
D506	————	MA110TW	DIODE	(GC) Addition
COIL (S)				
L2	RLV2N008-0	RLV2N010-0	COIL, AM ANT	(E, EG, GN) Change
		RLV2N011-0	COIL, AM ANT	(GC) Charge
FILTER (S)				
CF1	RLFFETWLA03D	RLFAPFB459J	FILTER, AM	(E, EG, GN) Change
		RLFAPFB450J	FILTER, AM	(GC) Change
CF2	RLFFETWLA03D	RLFFETWA03D	FILTER, FM	Change
CF3	RLFAPFB450J	RLFFEHWLA03D	FILTER, FM	Change
SWITCH (ES)				
S501	————	RSS2A003-A	SW, AM STEP	(GC) Addition
RESISTOR (S)				
R19	ERJ3GEYJ100V	ERJ6GEYJ100V	RESISTOR, 1/10W 10	Change
R301	ERJ3GEYJ102V	ERJ3GEYJ182V	RESISTOR, 1/16W 1.8K	Change
R305	ERJ6GEYJ272V	ERJ6GEYJ392V	RESISTOR, 1/10W 3.9K	Change
R516	————	ERJ6GEYJ105V	RESISTOR, 1/10W 1M	(GC) Addition
R518	————	ERJ6GEYJ224V	RESISTOR, 1/10W 220K	(GC) Addition
JUMPER RESISTOR (S)				
RJ1	ERJ6GEYJ000V	ERJ6GEY0R00V	CHIP JUMPER	Change
RJ4	ERJ3GEYJ000V	————	————	Deletion
CAPACITOR (S)				
C7	ECUV1H050DCN	————	————	Deletion
C22	ECST0GB226RR	ECST0GB106RR	CAPACITOR, 4V 10μ	Change
C44	ECEA0JKS101I	ECEA0GKS101I	CAPACITOR, 4V 100μ	Change
C147	ECEA1EK2R2L	ECEA1EKS2R2L	CAPACITOR, 25V 2.2μ	Change
C148	ECUV1E473MBN	ECUV1E473ZF	CAPACITOR, 25V 0.047μ	(GC) Change
		————	————	(E, EG, GN) Deletion

Ref. No.	Change of Part No.		Part Name & Description	Remarks
	RQ-V500 (P)	RQ-V500 (E, EG, GC, GN)		
C155	ECUV1C154KR	ECUV1C154ZFM	CAPACITOR, 16V 0.15μ	Change
C255	ECUV1C154KR	ECUV1C154ZFM	CAPACITOR, 16V 0.15μ	Change
C364	ECUV1E103MBV	ECUV1E103ZFV	CAPACITOR, 25V 0.01μ	Change
C513	—	ECUV1C223MBV	CAPACITOR, 16V 0.022μ	(GC) Addition
C517	ECUV1E103MBV	—	—	Deletion
CABINET AND CHASSIS				
16	—	RSC0123	SHIELD PLATE (B)	Addition
21	RFKJQV500P-K	RFKJQV500E-K	BOTTOM BOARD ASS'Y	(E, EG) Change
		RFKJQV500GC	BOTTOM BOARD ASS'Y	(GC) Change
		RFKJQV500P-K	BOTTOM BOARD ASS'Y	(GN)
28	RJB0352A	RJB0352A-2	PANEL SW P.C.B.	Change
MECHANISM PARTS				
109	—	RHW42002	WASHER	Addition
110	RXY0007	RFKRQV500P-K	MECHANISM BLOCK	Change
110D	RML0033-1	—	—	Deletion
110E	RHR3331ZB	—	—	Deletion
110F	RME0006	—	—	Deletion
PACKING MATERIAL				
P1	RPK0126	RPK0148	GIFT BOX	Change
P2	RPN0294	RPN0336	CUSHION	Change
P3	RPN0312	RPN0337	PAD	Change
P4	RPQ0024	XZB12X18A04	PROTECTION BAG	Change
ACCESSORIES				
A1	RQT0339-P	RQT0450-E	INSTRUCTION MANUAL	(E, EG) Change
		RQT0451-G	INSTRUCTION MANUAL	(GC, GN) Change
A2	RQX9028ZD	RQCB0169	SERVICENTER LIST	Change
A4	RP-HT106PY	RP-HV135SY-0	HEADPHONES	(E, EG) Change
		RP-HV134SY-0	HEADPHONES	(GC, GN) Change
A5	—	RQA0013A	WARRANTY CARD	(E, EG) Addition
A5	—	RQX7434ZA	WARRANTY CARD	(GN) Addition

■ CABINET PARTS LOCATION




■ MECHANISM PARTS LOCATION




PRINTED CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM

A
B
C
D
E
F
G



- Notes:**
This diagram shows a front view of the IC mounting surface.
1. The circuit shown in () on the conductor indicates printed circuit on the back side of the printed circuit board.
 2. The circuit shown in () on the conductor indicates printed circuit on the front side of the printed circuit board.
 3. The symbols (•) shown in the circuit board indicate connection points between conductors on the front side and back side of the circuit board.
 4. — : Chip resistor
 5. — : Chip jumper (0Ω)
- This circuit board diagram may be modified at any time with the development of new technology.

SCHEMATIC DIAGRAM



Notes)


- S1: XBS switch in "OFF" position.
- S2: Dolby NR/FM mode switch in "M/I" position. (S/II...ON/ST/II, M/I...OFF/MONO/I)
- S3: Hold switch in "OFF" position.
- S4: FM sens (sensitivity)/REV mode switch in "L/C" position. (L/C...LOCAL/C, D/C...DX/C)

- S5: Selector switch in "TAPE" position. (F...FM, A...AM, T...TAPE)
- S6: FWD/REV. switch in "FWD" position. (F...FWD, R...REV)
- S12: Leaf switch (open/close).
- S13: Leaf switch (Metal) in "OFF" position.

- S501: AM frequency step selector switch on "10kHz" step position... (GC) only.
- S601: Play/direction/M. select switch.
- S602: Stop/memory switch.
- S603: FF/UP switch.
- S604: Rewind/down switch.
- S605~607: Direct memory switches. [S605 : 3, S606 : 2, S607 : 1]

- VR1: FM MPX adjustment VR.
- VR141: Volume control.
- VR301: Tape speed adjustment VR.
- DC voltage measurements are taken with electronics voltmeter from negative terminal of battery.
- < >...FM, ()...AM, No mark...Playback








- Battery current: No signal: (AM)...
- Tape playback: 140m...
- 74dB/m • 30% MOD 54m...
- 60dB • 30% MOD 71m...



- | | | |
|--|--|---|
| <p>“TAPE” position.</p> <p>TAPE)</p> <p>h “FWD” position.</p> <p>close).</p> <p>in “OFF” position.</p> | <ul style="list-style-type: none"> • S501: AM frequency step selector switch on “10kHz” step position...(GC) only. • S601: Play/direction/M. select switch. • S602: Stop/memory switch. • S603: FF/UP switch. • S604: Rewind/down switch. • S605~607: Direct memory switches. <p>[S605 : 3, S606 : 2, S607 : 1]</p> | <ul style="list-style-type: none"> • VR1: FM MPX adjustment VR. • VR141: Volume control. • VR301: Tape speed adjustment VR. • DC voltage measurements are taken with electronics voltmeter from negative terminal of battery. <p>< >...FM, ()...AM, No mark...Playback</p> |
|--|--|---|
- 7 —

- **Battery current:**
 - No signal: (AM)...47.2mA (VR: MAX)
(FM)...59.2mA (VR: MAX)
 - Tape playback: 140mA (VR: MAX)
- 74dB/m • 30% MOD 54mA (VR max)
- 60dB • 30% MOD 71mA (VR max)

- This schematic diagram may be modified at any time with the development of new technology.

- development of new technology.
- | | | | |
|---|-----------------------------|---|-----------------|
|  | : FM/AM Vcap CONTROL SIGNAL |  | : ⊕ B LINE |
|  | : AM SIGNAL |  | : FM OSC SIGNAL |
|  | : PLAYBACK SIGNAL |  | : AM OSC SIGNAL |
|  | : MAIN (TAPE/RADIO) SIGNAL | | |

Service Manual

Stereo Radio Cassette Player

Mini Cassette
RQ-V500



Color

(K)... Black Type

Area

Country Code	Area	Color
(P)	U.S.A.	(K)
(PC)	Canada.	

* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby" and the double-D symbol are trade marks of Dolby Laboratories Licensing Corporation.


AR90 MECHANISM SERIES

SPECIFICATIONS

General:

Power Requirement: Battery; 3V (two R6/LR6, "AA" size batteries)
AC; with optional Panasonic AC adaptor RP-AC33

Power Output: 15mW + 15mW...RMS (max.)

Input: DC IN; 3V (mini type) 

Output: Headphones; 20Ω, ϕ3.5

Dimensions: 4 7/16" × 3 7/16" × 1 1/16"
(113 × 87.7 × 26.6mm)

Weight: 6.7 oz (190g) without batteries

Radio Section:

Radio Frequency Range: FM; 87.5~108 MHz
AM; 520~1710 kHz

Intermediate Frequency: FM; 10.7 MHz
AM; 450 kHz

Sensitivity: FM; 3.5μV/ -3dB Limit sense
AM; 316μV/m/0.1 mW output

Tape Deck Section:

Frequency Response: Normal; 30~18,000 Hz
CrO₂; 30~18,000 Hz
Metal; 30~18,000 Hz

Motor: Electrical governor motor

Track System: 4-track 2-channel stereo playback

Tape Speed: 1-7/8 ips (4.8cm/s)

Design and specifications are subject to change without notice.

Panasonic®

Matsushita Services Company
Division of Matsushita Electric
Corporation of America
50 Meadowland Parkway,
Secaucus, New Jersey 07094

Panasonic Sales Company,
Division of Matsushita Electric
of Puerto Rico, Inc.
San Gabriel Industrial Park
65th Infantry Ave. Km.9.5
Carolina, P.R. 00630


Matsushita Electric
of Canada Limited
5770 Ambler Drive, Mississauga,
Ontario, L4W 2T3


CONTENTS

	Page
LOCATION OF CONTROLS	2, 3
PROCEDURE FOR THE REPLACEMENT OF THE MECHANISM BLOCK	4
PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM	5
DISASSEMBLY INSTRUCTIONS	6 ~ 8
HOW TO CHECK OPERATIONS DURING DISASSEMBLY AND SERVICING	9, 10
MEASUREMENTS AND ADJUSTMENTS	11, 12
SCHEMATIC DIAGRAM	13 ~ 15

	Page
PRINTED CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM	16, 17
TERMINAL GUIDE OF IC'S, TRANSISTORS AND DIODES	18
INTERNAL CONNECTION OF LCD	18
TERMINAL FUNCTIONS OF IC	19
REPLACEMENT PARTS LIST	20 ~ 22
CABINET PARTS LOCATION	23
MECHANISM PARTS LOCATION	23
RESISTORS & CAPACITORS	24 ~ 25

LOCATION OF CONTROLS




*Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
 "DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

Power Source

Battery Operation

Install the "AA" size batteries (Panasonic R6/LR6 or equivalent) as shown in the figure.



Notes:

- Batteries installed with incorrect polarities may leak and damage this unit.
- Replace with fresh batteries of the same kind. Observing Polarity.

Battery removal

Press battery "2" toward the ⊖ battery terminal and remove it.

Battery life

When the batteries are weak, the unit will turn the stop/off condition, all the indicators except HOLD Indicator will disappear and the BATT Indicator will flash on and off.

Replace them with new ones as soon as possible.

To keep the memorized contents for radio, the replacement must be done within 30 seconds.


BATTERY SERVICE LIFE

	(EIAJ)	
	Playback (hour)	Radio (hour)
Panasonic UM-3/R6	3.2	12
LR6 (Panasonic Alkaline)	8.5	27

The above battery service life is measured according to the conditions set forth by EIAJ (Electronic Industries Association of Japan). As the battery service life varies with the method of operation and environmental conditions, use these values as reference.

AC Power Operation

Connect the AC adaptor (Use only Panasonic AC adaptor, RP-AC33, optional) as shown in the figure.



Radio Reception

1. Release the hold condition.
2. Set the **SELECTOR Switch** to "AM" or "FM".
 - The BATT Indicator and the frequency display will appear.
3. Press the **UP or DOWN Button** to tune in your favorite station.

Manual Tuning Pressing either of the UP or DOWN Buttons one by one makes the frequency display change.
(AM step by 10 kHz, FM Step by 0.1 MHz)
Repeat the pressing until the frequency of the desired station appears.

Auto Search

Tuning To automatically tune stations, press the UP or DOWN Button for more than 0.5 seconds. The unit will begin to search up or down from the currently displayed frequency. When a station is located, the frequency is held for two (2) seconds and then the unit will continue to search for the next broadcast. When the desired station has been found, press the UP or DOWN Button again and the search function will be stopped.

Note:

It may be necessary to use the Manual Tuning procedure to "fine tune" a station that has been located using the Auto Search feature.

4. Adjust the volume using the **VOLUME Control**.

To turn off the radio, set the **SELECTOR Switch** to "TAPE/[OFF]".

Antenna

FM: The stereo headphones' cord works as an antenna. Use it extended not coiled.

AM: The Built-in ferrite core AM antenna is somewhat directional. It may be necessary to turn the unit to obtain the good receiving condition.

To memorize into memory channels from 1 to 6

1. Receive the station to be memorized.
2. Press the **MEMORY Button**.
 - The [M] Indicator will flash on and off for 10 seconds.
3. During flashing (for 10 seconds), press the **M. SELECT Button** to select the memory channel (1-6) to be memorized.
 - The Memory Channel Number will appear and each time the M. SELECT Button is pressed, the Memory Channel Number will change from 1 to 6 and return.
4. Press the **MEMORY Button** to enter the memory.
 - The three beeps will be emitted.
 - The [M] Indicator will light.

Note:

The previous memory will be cleared when the new memory is entered into the same memory channel.

How to tune in the memorized station

Direct tuning using the 1, 2 or 3 Button

1. Set the **SELECTOR Switch** to your desired band ("AM" or "FM").
2. Release the hold condition.
3. Press one of the 1, 2 and 3 Buttons to receive your desired station.

Memory channel tuning


1. Set the **SELECTOR Switch** to your desired band ("AM" or "FM").
2. Release the hold condition.
3. Press the **M. SELECT Button** until the desired memory channel number appears.

Last One Memory

This memory is used during radio-off. When the radio is turned on, the frequency received before it was turned off is tuned in again.

How to clear the unnecessary memory channels

You can clear the unnecessary memory channels for your convenience. (EX. 1→2→3→4→5→6)



1. Recall the unnecessary memory channel on the display.

FM MODE Selector

To receive FM stereo broadcasts, set the FM MODE Selector to "ST". If reception is poor (excessive noise), set to "MONO". This will reduce the noise and provide clear reception; however, the broadcast will not be heard in stereo.

- When receiving the FM stereo broadcasts, the STEREO Indicator will appear.

Note:

When an AM broadcast is received, to reduce the unwanted beat signals, set the FM MODE Selector to whichever (I or II) position best reduces these "beat" signals. The "beat" signals normally sound like a whistle.

FM SENS (sensitivity) Selector

This is helpful for receiving FM broadcast clearly.

Normally set this selector to "DX".

When the FM reception is impaired or there is interference from a powerful station, set to "LOCAL".

This does not function for AM reception.

How to memorize the broadcasting station

9 stations (including 3 direct-tuning stations) can be memorized for each band.

To memorize into 1, 2, 3 Buttons (for direct tuning)

1. Receive the station to be memorized.

2. Press the **MEMORY Button**.

- The [M] Indicator will flash on and off for 10 seconds.

3. During flashing (for 10 seconds), press one of the 1, 2 and 3 Buttons to be memorized.

- The three beeps will be emitted.

- The DIRECT Indicator and Memory Channel Number will appear.

- The [M] Indicator will light.

Another method

1. Press one of the 1, 2 and 3 Buttons.
2. Press the **MEMORY Button**.
3. Tune in your desired station.
4. Press the **MEMORY Button**.

2. Press the **MEMORY Button**.

- The [M] Indicator will flash on and off for 10 seconds.

3. During flashing, press both of the UP and DOWN Buttons at one time for more than one second.

- The frequency display will disappear.

- The "---" will appear.

4. Press the **MEMORY Button**.

- The three beeps will be heard.

- The [M] Indicator will disappear.


Notes:

- The "---" display can not be memorized into the 1, 2 or 3 Button. If you press the one of the 1, 2 and 3 Buttons after the "---" is displayed, the five beeps will be emitted.

- The cleared channels can be reset to a new station by performing the memorization procedure above.

Maintenance

The head assembly, Capstans, and Pressure rollers are in constant contact with the tape. If these parts are dirty, the sound quality will be impaired. Periodically, clean these parts as shown.



Notes:

- If the head assembly is extremely dirty, clean it with a soft cloth dampened with a little alcohol.
- The use of cleaning tapes is not recommended, as some are abrasive and may cause premature wear of the heads. Simply, clean the head assembly as described.
- Do not clean the plastic cabinet with benzine or thinner. Clean it with a cloth, dampened in a mild solution of soap and water. Avoid excessive moisture.
- Avoid spray-type insecticides. Some insecticides contain chemicals that could cause cabinet deformation.

■ PROCEDURE FOR THE REPLACEMENT OF THE MECHANISM BLOCK

•How to replace the mechanism block

The mechanism block is supplied without other parts as a semi-assembly. The head block, motor, belt and plunger are supplied separately from the mechanism block.

If the mechanism block is exchanged as a replacement assembly, follow the preparation procedure below.

Preparation procedure

Remove the head block, motor, belt and plunger from the mechanism to be replaced and replace those parts to the new mechanism block.

(Refer to the "PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM".)




Fig. 1

※ The adjustment of the mechanism block is unnecessary after replacement.

•How to replace the head block

The head and pinch roller are supplied together in the head block. The pinch roller is also supplied separately.

Preparation procedure

The head block for replacement is not supplied with a holder as shown in the figure below. Therefore, remove the holder from the block to be repaired and mount it to the new head block. Then, proceed to replace the head block. (Refer to "PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM".)




Fig. 2

※ Head azimuth adjustment is unnecessary.

PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM

•How to remove the mechanism

Follow the procedures in Ref. Nos. 1~8 in the Disassembly Instructions. (See pages 6~8.)

* After replacing the parts, refer to the notes for assembly. (See page 8.)

•How to remove the head block and pinch roller

1. Follow the procedures in Ref. Nos. 1, 2 and 8 in the Disassembly Instructions, remove the rear cabinet and cassette compartment lid. (See pages 6, 8.)
2. Remove 6 solders (Head FPC). (See Fig. 3.)
3. Remove 2 screws (①, ②) in order to remove the head block. (See Fig. 4.)
4. Remove 2 washers. (See Fig. 5.)
5. Remove 2 springs in order to remove the pinch roller. (See Fig. 6.)




Fig. 3




Fig. 4




Fig. 5




Fig. 6

•How to remove the plunger

1. Follow the procedures in Ref. Nos. 1~4 in the Disassembly Instructions. (See pages 6, 7.)
2. Remove one screw (①). (See Fig. 7.)
3. Remove the washer and lever in order to remove the plunger. (See Fig. 8.)




Fig. 7




Fig. 8

•How to remove the motor and belt

1. Follow the procedures in Ref. Nos. 1~4 in the Disassembly Instructions. (See pages 6, 7.)
2. Remove the washer and motor wheel to remove the belt from the motor pulley. (See Fig. 9.)
3. Remove 2 screws (①, ②) in order to remove the motor. (See Fig. 10.)
4. Remove 2 screws (③, ④) and then the attachment plate to remove the belt. (See Fig. 11.)




Fig. 9




Fig. 10

•How to attach the belt

1. Attach the belt as shown in the figure. (See Fig. 12.)
2. Mount the attachment plate and secure it with 2 screws. (See Fig. 12.)




Fig. 11





Fig. 12

DISASSEMBLY INSTRUCTIONS


THIS UNIT CONTAINS F.P.C. BE CAREFUL NOT TO CUT OR DAMAGE THE FOIL DURING DISASSEMBLY.

Ref. No. 1 Removal of the LCD cabinet

Procedure 1




1. Remove the battery cover.
2. Remove 1 screw (❶).




3. Press the open button to open the cassette lid.
4. After pushing section (A) on the rear cabinet slightly, remove claw (a) and then claw (b).

Ref. No. 2 Removal of the rear cabinet

Procedure 1→2




1. Remove 5 screws (❶~❺).




2. Pull the section (A) on the rear cabinet in the direction of arrow ❶ and then remove it in the direction of arrow ❷. (※Pull it so that the switches and controls are disengaged.)

Ref. No. 3 Removal of the switch P.C.B.






Procedure 1→2→3






1. Remove 1 screw (❶).
2. Unsolder the 3 points on the connection terminal between the main P.C.B. and Switch P.C.B.





3. Remove the rear cabinet in the direction of arrow ❸.

Ref. No. 4	Removal of the main P.C.B.		
Procedure 1→2→3→4			
	<ol style="list-style-type: none"> 1. Remove 18 solders on the LCD FPC. 2. Remove 5 solders on the head FPC. 3. Remove one solder on the terminal. 4. Remove 2 solders on the solenoid terminal. 5. Remove 4 solders on the motor terminal. 6. Remove the soldered point on the battery ⊕ terminal and then remove the battery terminal in the direction of the arrow. 7. Remove the soldered point on the battery ⊖ terminal and then remove the battery terminal in the direction of the arrow. 8. Remove 3 screws (①~③). 		
Ref. No. 5	Removal of the LCD P.C.B.		
Procedure 1→5			
	<ol style="list-style-type: none"> 1. Release 2 claws in the direction of arrows. 2. Remove 18 solders on the LCD FPC. 		
Ref. No. 6	Removal of the battery box chassis	Ref. No. 7	Removal of the angle ass'y
Procedure 1→2→3 →4→6		Procedure 1→2→3 →4→6→7	
	<p>• Push the chassis in the direction of arrow ① and remove it in the direction of arrow ②.</p>		<p>• Remove 2 screws (①, ②).</p>

Ref. No. 8	Removal of the cassette lid	Ref. No. 9	Removal of the cassette open lever
Procedure 8	 <ol style="list-style-type: none"> 1. Press the open button to open the cassette lid. 2. Remove 3 screws (①~③) and then remove the cassette lid. 		
Ref. No. 10	Removal of the DOLBY NR/FM MODE knob, SELECTOR knob, XBS knob	Ref. No. 11	Removal of the FM SENS/REV MODE knob, HOLD knob
Procedure 1→2→10	 <p>• Release the claw in the direction of arrow.</p>		
		Procedure 1→2→11	 <p>• Release the claw in the direction of arrow.</p>

Notes for assembly**■ How to install the battery box chassis**



- Engage hole A of the angle ass'y in the rib of the battery box chassis.

**■ How to install the rear cabinet and the slide controls**

- Engage the rear cabinet with the headphone jack and open button and then install it in the direction of the arrow as shown in the figure above.

■ How to install the main P.C.B.

- Engage the switch in the lever of the mechanism.



- Install the slide controls so that the switch bosses are engaged with the slide controls.

HOW TO CHECK OPERATIONS DURING DISASSEMBLY AND SERVICING

Check operations during disassembly following the steps.

- 1) Set the condition as shown in Fig. 1 in accordance with Ref. Nos. 1, 2, 4 and 5 on pages 6 and 7 of the Disassembly Instructions. (DO NOT remove the solders on the head and LCD FPCs.)
- 2) Connect the PCB and motor with the extension cord (RFKZ0002).
- 3) Solder the following transistors and IC terminal with a lead wire and then short-circuit them.

- Short-circuit between Q508 base and the ground.
- Short-circuit between Q353 collector and emitter.
- Short-circuit between IC5 ⑧ pin and Q303 emitter.

Note: See pages 9 and 10 for the points to be short circuited.

- 4) Connect the AC adaptor to DC in jack (See Fig. 1)
- 5) Connect the ground terminal foil and the mechanism ground pin with a lead wire (mechanism earth).
- 6) Manually operate the plunger when checking the PLAY/STOP operation.

Note: • Operate the plunger manually. Even if the operation buttons are pressed, the plunger will not be actuated.

- Even if the mechanism unit is switched to the REV mode in Step 6, the head change-over switch (IC3) will remain in the FWD position, so set the FWD mode to check the audio.





Fig. 1


• Short circuit point

(1) SCHEMATIC DIAGRAM



Short circuit between IC5 ⑧ pin and Q303 emitter.


(2) SCHEMATIC DIAGRAM



Short circuit between Q353 collector and emitter. (Short land ⑥)

Short circuit between Q508 base and ground. (Short land ①)

(1) PRINTED CIRCUIT BOARD



Short circuit between Q353 collector and emitter. (Short land ⑥)

Short circuit between Q508 base and ground. (Short land ①)

Short circuit between IC5 ⑧ pin and Q303 emitter.

MEASUREMENTS AND ADJUSTMENTS

• ALIGNMENT INSTRUCTION

READ CAREFULLY BEFORE ATTEMPTING ALIGNMENT					
1. Set volume control to maximum.			6. Set Tape Selector Switch to normal.		
2. Set band/reverse mode switch to FM ST, FM and AM.			7. Set XBS switch to OFF.		
3. Set function selector switch to radio or tape.			8. Output of signal generator should not be higher than necessary to obtain an output reading.		
4. Set power source voltage to 3.0V DC.					
5. Set Dolby NR switch to OUT.					

• AM ADJUSTMENT

BAND	SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT POINT	REMARKS
	CONNECTIONS	FREQUENCY				
AM-RF ADJUSTMENT						
AM	Fashion loop of several turns of wire and radiate signal into loop of receiver.	600 kHz	Tune to signal.	Headphones jack (20Ω) (Refer to Fig. 1)	(※ 1) L2 (AM ANT Coil)	Adjust for maximum output. Adjust L2 by moving coil bobbin along ferrite core.
AM		1,500 kHz			CT1 (AM ANT Trimmer)	Adjust for maximum output.
(*1) Cement antenna bobbin with wax after completing alignment.						

• FM ADJUSTMENT

BAND	SIGNAL GENERATOR or SWEEP GENERATOR		RADIO DIAL SETTING	INDICATOR (ELECTRONIC VOLTMETER or OSCILLOSCOPE)	ADJUSTMENT POINT	REMARKS
	CONNECTIONS	FREQUENCY				
FM-RF ADJUSTMENT						
FM	Connect to test point TP3 through FM dummy antenna. Negative side to test point TP4.	106 MHz	Variable capacitor fully open.	Headphones jack (20Ω) (Refer to Fig. 1)	CT2 (FM OSC Trimmer)	(*2) Adjust for maximum output.
FM VCO ADJUSTMENT						
FM	—	—	108 MHz	TP8 ... (+) TP9 ... (—)	CT3	Adjust CT3 for 9.0V ±0.4 V reading on DC digital voltmeter.
FM MPX ADJUSTMENT						
FM	Connect to test point TP3 through FM dummy antenna. Negative side to TP4.	98 MHz, 60 dB (CW)	98 MHz	TP1 ... (+) TP2 ... (—)	VR1	<ul style="list-style-type: none">• Set FM Mode/SENS. Switch to ST/LOCAL.• Adjust VR1 for 19 kHz ±50 Hz reading on frequency counter.
(*2) Three output responses will be present; proper tuning is the center frequency.						

• TAPE DECK ADJUSTMENT

ITEM	TEST TAPE	MEASUREMENT POINT	ADJUSTMENT POINT	PROCEDURE
Tape speed	QZZCWAT (3kHz, -10dB)	Headphones jack (20Ω) (Refer to Fig. 1)	VR301 (Refer to Fig. 2)	Playback the central part of the tape and adjust VR301 so that the tape speed is as follows. Forward: $2,940 \pm 10Hz$ Reverse: $3,000 \pm 80Hz$

Note: The playback head is supplied on the head arm assembly. (See the Mechanism parts location on page 23.)
The assembly requires no adjustment.

• ADJUSTMENT POINT

* Please refer to the Printed Circuit Board and Wiring connection Diagram for test point locations.




Fig. 1





Fig. 2


SCHEMATIC DIAGRAM

A MAIN CIRCUIT






Notes)

- S1: XBS switch in "OFF" position.
- S2: Dolby NR/FM mode switch in "M/I" position. (S/II...ON/ST/II, M/I...OFF/MONO/I)
- S3: Hold switch in "OFF" position.
- S4: FM sens (sensitivity)/REV mode switch in "L/C" position. (L/C...LOCAL/C, D/D...DX/D)
- S5: Selector switch in "TAPE" position. (F...FM, A...AM, T...TAPE)
- S6: FWD/REV. switch in "FWD" position. (F...FWD, R...REV)
- S12: Leaf switch (open/close).
- S13: Leaf switch (Metal) in "OFF" position.
- S601: Play/direction/M. select switch in "OFF" position.
- S602: Stop/memory switch in "OFF" position.
- S603: FF/UP switch in "OFF" position.
- S604: Rewind/down switch in "OFF" position.
- S605~607: Direct memory switches. [S605 : 3, S606 : 2, S607 : 1]
- VR1: FM MPX adjustment VR.
- VR141: Volume control VR.
- VR301: Tape speed adjustment VR.
- DC voltage measurements are taken with electronics voltmeter from negative terminal of battery.
- < >...FM, ()...AM, No mark...Playback




- **This schematic diagram may be modified at any time with the development of new technology.**

Legend for the schematic diagram symbols:

-  : FM/AM Vcap CONTROL SIGNAL
-  : AM SIGNAL
-  : PLAYBACK SIGNAL
-  : MAIN (TAPE/RADIO) SIGNAL
-  : ⊕ B LINE

PRINTED CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM




















Notes:

This diagram shows a front view of the IC mounting surface.

1. The circuit shown in (●) on the conductor indicates printed circuit on the back side of the printed circuit board.
2. The circuit shown in (○) on the conductor indicates printed circuit on the front side of the printed circuit board.
3. The symbols (●) shown in the circuit board indicate connection points between conductors on the front side and back side of the circuit board.
4. — : Chip resistor
5. — : Chip jumper (0Ω)


• This circuit board diagram may be modified at any time with the development of new technology.

■ TERMINAL GUIDE OF IC'S, TRANSISTORS AND DIODES


<p>TK11821MT1</p> 	<p>AN7415SE2</p> 	<p>AN7375NSE2</p> 	<p>LA4581MATEL NBC1675</p> 	<p>AN7007SUE2</p> 	<p>UPD1715G607</p> 
	<p>2SB815B7TW 2SB1218STW 2SC3930TW 2SC3935QTW 2SD1819STW 2SD1328STW</p>	<p>UN5115TW UN5116TW UN5213TW UN5215TW UN5216TW</p>	<p>2SK543DTW</p> 	<p>XN1213TW XN1215TW XN1401TW</p> 	<p>XN4215TW XN4501TW</p> 
<p>MA720TW SB00703QTR</p> 	<p>MA141WKTW SB007W03QTR</p> 	<p>MA159TW</p> 	<p>IMN10T109</p> 	<p>S80718AFT1 S80720DHT1</p> 	<p>FMN1T99</p> 
<p>PQ5020543</p> 					

■ INTERNAL CONNECTIONS OF LCD

• Common connection diagram



• Segment connection diagram



■ TERMINAL FUNCTIONS OF IC

• IC6 (UPD1715G607): SYSTEM CONTROL & LCD DRIVE

Terminal No.	Terminal Name	I/O	Function	Terminal No.	Terminal Name	I/O	Function
1 └ 10	LCD10 └ LCD1	O	Outputs terminals for LCD segment signals.	28	XO	O	Terminals used for connecting a quartz oscillator.
11 └ 13	COM3 └ COM1	O	Outputs terminals for LCD common signals.	29	XI	I	
14	V _{SS} 3	—	Condenser external terminals.	30 └ 33	PA3 └ PA0	I	Data signal input terminal
15	CAP2	—		34	PB3	O	Outputs the timer out terminal.
16	CAP1	—		35	PB2	O	Band select output terminal.
17	V _{SS} 2	—		36	PB1		
18	VDP	O	Outputs the power out terminal.	37	PB0	O	Muting signal output terminal.
19	CGP	O	Outputs the buzzer out terminal.	38 └ 40	PC3 └ PC1	O	Key return signal source output terminals for momentary switch on the key matrix.
20, 46	V _{DD}	—	Power terminal.	42	PC0		
21	M	I	Inputs the prescaler divider ratio select signal.	41, 54	NC	—	—
22	VCOH	I	Inputs the local oscillator (VCO) (10~130 MHz)	43 └ 45	K3 └ K1	I	Terminals for Key return signal input.
23	VCOL	I	Inputs the local oscillator (VCO) (0.5~40 MHz)	47	K0		
24	V _{SS} 1	—	For ground connection.	48 └ 53	LCD16 └ LCD11	O	Output terminals for LCD segment signals.
25	EO1	O	PLL error output terminal.				
26	EO2						
27	CE	I	Device select signal input terminal.				

REPLACEMENT PARTS LIST

Notes : * Important safety notice:

Components identified by \triangle mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.

* The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.) Parts without these indications can be used for all areas.

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)				DIODE(S)	
IC1	AN7007SUE2	IC, FM/AM IF AMP		D51	MA141WKTW	DIODE	
IC2	AN7415SE2	IC, MPX		D141	SB00703QTR	DIODE	
IC3	LA4581MATEL	IC, PRE-POWER		D353	SB00703QTR	DIODE	
IC4	AN7375NSE2	IC, DOLBY NR		D500	SB007W03QTR	DIODE	
IC5	NBC1675	IC, MOTOR DRIVE		D501, 502	IMN10T109	DIODE	
IC6	UPD1715G607	IC, MICRO COMPUTER		D503	MA159TW	DIODE	
IC7	TK11821MT1	IC, DD CONV.		D507	MA720TW	DIODE	
IC8	S80720DHT1	IC, RESET		D601, 602	FMN1T99	DIODE	
IC9	S80718AFT1	IC, RESET				VARIABLE RESISTOR(S)	
		TRANSISTOR(S)		VR1	RVNEA14B1WF	V. R, FM MPX ADJ.	
Q2	2SK543DTW	TRANSISTOR		VR141	EVUAEAT43C54	V. R, VOLUME	
Q3	2SC3930BTW	TRANSISTOR		VR301	RVNEA53B1W-F	V. R, TAPE SPEED ADJ.	
Q4	2SC3935-Q	TRANSISTOR				VARIABLE CAPACITOR(S)	
Q5	2SD1819STW	TRANSISTOR					
Q141	UN5215-Q	TRANSISTOR		VC1	RVDSVC341PCT	V. C, AM	
Q142	XN1215TW	TRANSISTOR		VC2, 3	RVDSVC203ATW	V. C, FM RF & OSC	
Q151	UN5213TW	TRANSISTOR				COMPONENT COMBINATION(S)	
Q301, 302	UN5215-Q	TRANSISTOR					
Q303	UN5115TW	TRANSISTOR		Z1	RCRBMTO01-H	B. P. F.	
Q351	XN4215TW	TRANSISTOR				COIL(S)	
Q352, 353	2SB815B7TW	TRANSISTOR					
Q354	UN5213TW	TRANSISTOR		L1	RL02A006-M	COIL, AM OSC	
Q355	UN5216TW	TRANSISTOR		L2	RLV2N008-0	COIL, AM ANT	
Q356	2SK543DTW	TRANSISTOR		L3	RL04Y219-0	COIL, FM RF	
Q357, 358	2SD1819STW	TRANSISTOR		L4	RL04Y220-0	COIL, FM OSC	
Q381	UN5213TW	TRANSISTOR		L101	RLFJFCR47KTD	COIL	
Q382	XN1213TW	TRANSISTOR		L141	RLFJFCR47KTD	COIL	
Q501	2SD1819STW	TRANSISTOR		L201	RLFJFCR47KTD	COIL	
Q502	RVSGP2S24BC	TRANSISTOR		L301	RL09U009T-T	COIL	
Q503	XN4501TW	TRANSISTOR				FILTER(S)	
Q504	UN5116TW	TRANSISTOR					
Q505	2SD1328STW	TRANSISTOR		CF1	RLFFETWLA03D	FILTER, AM	
Q506	2SB1218STW	TRANSISTOR		CF2	RLFFETWLA03D	FILTER, FM	
Q507	UN5116TW	TRANSISTOR		CF3	RLFAPFB450J	FILTER, FM	
Q508, 509	2SD1819STW	TRANSISTOR				OSCILLATOR(S)	
Q510, 511	XN1401TW	TRANSISTOR					
Q512	2SB1218STW	TRANSISTOR		X1	RLFDFTA03D	OSCILLATOR	
Q513	XN1213TW	TRANSISTOR		X501	RSXD75K0S04	OSCILLATOR	
Q515	UN5213TW	TRANSISTOR					
Q516	2SB1218STW	TRANSISTOR					
Q517	XN4501TW	TRANSISTOR					

[illegible]

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET AND CHASSIS		107	RMA0023	HOLDER	
				108	RHE51472A	SCREW	
1	RGV0044-K	KNOB, SELECTOR		110	RXY0007	MECHANISM BLOCK	
2	RGV0045-K	KNOB, DOLBY NR/FM SENS&MODE		110A	RMQ0011	ANGLE	
3	RGV0045-R	KNOB, XBS		110B	RMQ0012	ANGLE	
4	RHD14008-K	SCREW		110C	RHD14006	SCREW	
5	RHD14018-K	SCREW		110D	RML0033-1	LEVER	
6	RHE50972A	SCREW		110E	RHR33312B	WASHER	
7	RHE5100YA	SCREW		110F	RME0006	SPRING	
8	RHE5119ZA	SCREW		111	RJR0053	CONNECTION TERMINAL	
9	RHE5169YA	SCREW		112	XQN14+AM14FN	SCREW	
10	RJC30006	BATTERY TERMINAL (+)				PACKING MATERIAL	
11	RJC70007	BATTERY TERMINAL (-)					
12	RKK0019-K	BATTERY COVER		P1	RPK0126	GIFT BOX	
13	RGW0068-K	KNOB, VOLUME		P2	RPN0294	PAD	
14	RMN0065	LCD HOLDER		P3	RPN0312	PAD	
15	RSC0122	SHIELD PLATE (A)		P4	RPQ0024	PROTECTION SHEET	
						ACCESSORIES	
17	RSQ0012	CONNECTOR					
18	XSHR17+2FZ	SCREW		A1	RQT0339-P	INSTRUCTION MANUAL	(P)
19	RFKGQV500P-K	DISPLAY PANEL ASS'Y		A1	RQT0449-C	INSTRUCTION MANUAL	(PC)
20	RHD14018-K	SCREW		A2	RQX9028ZD	SERVICENTER LIST	
21	RFKJQV500P-K	BOTTOM BOARD ASS'Y		A3	RGQ0038-K	BELT CLIP	
22	RKQ0056-K	BATTERY BOX CHASSIS		A4	RP-HT106PY	HEADPHONES	
23	RMRO262-K	C. LOCK HOLDER					
24	RYF0060	CASSETTE LID ASS'Y					
24A	RHE50972A	SCREW					
24B	RHE5169YA	SCREW					
24C	RMA0284	LOCK ANGLE					
24D	RXM0002	LINK ANGLE ASS'Y					
25	RSH1B001-6U	LEAF SW.					
26	RJB0353	F. P. C.					
27	RJB0359	DET. SW P. C. B.					
28	RJB0352A	PANEL SW P. C. B.					
		MECHANISM PARTS					
101	HPX-24NB3A	MOTOR					
102	XQS14+A18FZ	SCREW					
103	RDV0003	BELT					
106	RXQ0006	HEAD BLOCK ASS'Y					
106A	RNW1012A	WASHER					
106B	RME0004-1	SPRING					
106C	RME0005	SPRING					
106D	RXL0004	PINCH ROLLER ARM					
106E	RXL0005	PINCH ROLLER ARM					

RESISTORS & CAPACITORS

Notes : * Capacity value are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
 * Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM) , 1M=1,000k (OHM)

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks
			R158	ERJ3GEYJ332V	1/16W 3.3K	R530	ERJ6GEYJ104V	1/10W 100K
			R171	ERJ3GEYJ100V	1/16W 10	R531	ERJ3GEYJ474V	1/16W 470K
			R201	ERJ6GEYJ821V	1/10W 820			
			R202	ERJ3GEYJ273V	1/16W 27K			JUMPER RESISTOR(S)
		RESISTORS	R203	ERJ6GEYJ684V	1/10W 680K			
			R204, 205	ERJ3GEYJ102V	1/16W 1K	RJ1	ERJ6GEYJ000V	CHIP RESISTOR
R1	ERJ3GEYJ220V	1/16W 22	R206	ERJ3GEYJ222V	1/16W 2.2K	RJ4	ERJ3GEYJ000V	CHIP RESISTOR
R2	ERJ3GEYJ560V	3W 56	R208	ERJ3GEYJ472V	1/16W 4.7K			
R3	ERJ3GEYJ104V	1/16W 100K	R209	ERJ6GEYJ473V	1/10W 47K			CAPACITORS
R4	ERJ3GEYJ562V	1/16W 5.6K	R251	ERJ3GEYJ152V	3W 1.5K			
R6	ERJ3GEYJ101V	1/16W 100	R253	ERJ3GEYJ224V	1/16W 220K	C1	ECUV1H103ZFN	50V 0.01U
R7	ERJ3GEYJ224V	1/16W 220K	R254	ERJ3GEYJ822V	1/16W 8.2K	C3	ECUV1H120JCN	50V 12P
R9	ERJ3GEYJ152V	3W 1.5K	R256	ERJ3GEYJ184V	3W 180K	C4	ECUV1H431GCN	50V 430P
R10	ERJ3GEYJ102V	1/16W 1K	R257	ERJ3GEYJ363V	3W 36K	C5	ECUV1C104MBM	16V 0.1U
R11	ERJ3GEYJ273V	1/16W 27K	R258	ERJ3GEYJ332V	1/16W 3.3K	C7	ECUV1H050DCN	50V 5P
R13	ERJ3GEYJ103V	1/16W 10K	R301	ERJ3GEYJ102V	1/16W 1K	C10	ECUV1H102MBV	50V 1000P
R14	ERJ3GEYJ334V	1/16W 330K	R302	RRSN15J103UE	1/20W 10K	C12	ECUV1H101KCV	50V 100P
R15	ERJ3GEYJ122V	3W 1.2K	R303	ERJ3GEYJ123V	3W 12K	C13	ECUV1E103MBV	25V 0.01U
R16	ERJ3GEYJ473V	1/16W 47K	R304	ERJ6GEYJ103V	1/10W 10K	C14	ECUV1H560KCV	50V 56P
R17	ERJ3GEYJ474V	1/16W 470K	R305	ERJ6GEYJ272V	1/10W 2.7K	C16	ECUV1C223MBV	16V 0.022U
R18	ERJ3GEYJ224V	1/16W 220K	R306	ERJ6GEYJ221V	1/10W 220	C17	ECUV1H221KBV	50V 220P
R19	ERJ3GEYJ100V	1/16W 10	R307	ERJ6GEYJ103V	1/10W 10K	C19	ECUV1C224ZFN	16V 0.22U
R20	ERJ3GEYJ681V	3W 680	R351, 352	ERJ3GEYJ221V	1/16W 220	C20	ECUV1E473MBN	25V 0.047U
R21	ERJ3GEYJ102V	1/16W 1K	R353	ERJ3GEYJ100V	1/16W 10	C21	ECUV1C223MBV	16V 0.022U
R22	ERJ3GEYJ474V	1/16W 470K	R355	ERJ6GEYJ104V	1/10W 100K	C22	ECST0GB226RR	4V 22U
R23	ERJ3GEYJ222V	1/16W 2.2K	R356	ERJ6GEYJ103V	1/10W 10K	C24	ECUV1H102MBV	50V 1000P
R24	ERJ3GEYJ104V	1/16W 100K	R357, 358	ERJ6GEYJ472V	1/10W 4.7K	C25	ECUV1H102MBN	50V 1000P
R25	ERJ3GEYJ103V	1/16W 10K	R359	ERJ6GEYJ682V	1/10W 6.8K	C26	ECUV1H040CCV	50V 4P
R26	ERJ6GEYJ561V	1/10W 560	R360	ERJ6GEYJ103V	1/10W 10K	C28	ECUV1H040CCV	50V 4P
R51	ERJ6GEYJ100V	1/10W 10	R361	ERJ3GEYJ103V	1/16W 10K	C29	ECUV1C223MBV	16V 0.022U
R52	ERJ3GEYJ153V	1/16W 15K	R500	ERJ3GEYJ103V	1/16W 10K	C30	ECUV1E223MBN	25V 0.022U
R53	ERJ3GEYJ102V	1/16W 1K	R501	ERJ3GEYJ101V	1/16W 100	C31, 32	ECUV1H100DCV	50V 10P
R54, 55	ERJ3GEYJ104V	1/16W 100K	R502	ERJ3GEYJ224V	1/16W 220K	C33	ECUV1H330KCV	50V 33P
R56	ERJ3GEYJ222V	1/16W 2.2K	R503	ERJ3GEYJ103V	1/16W 10K	C34	ECUV1H470KCV	50V 47P
R57	ERJ6GEYJ223V	1/10W 22K	R504	ERJ3GEYJ104V	1/16W 100K	C35-38	ECUV1C223MBV	16V 0.022U
R101	ERJ6GEYJ821V	1/10W 820	R505	ERJ3GEYJ105V	1/16W 1M	C39	ECUV1E103MBV	25V 0.01U
R102	ERJ3GEYJ273V	1/16W 27K	R507	ERJ3GEYJ105V	1/16W 1M	C40	ECEA0GKS221I	4V 220U
R103	ERJ6GEYJ684V	1/10W 680K	R508	ERJ3GEYJ474V	1/16W 470K	C41	ECUV1H471KBV	50V 470P
R104, 105	ERJ3GEYJ102V	1/16W 1K	R509	ERJ3GEYJ105V	1/16W 1M	C42	ECST0GB106RR	4V 10U
R106	ERJ6GEYJ222V	1/10W 2.2K	R511	ERJ3GEYJ101V	1/16W 100	C43	ECUV1H221KBV	50V 220P
R108	ERJ3GEYJ472V	1/16W 4.7K	R512	ERJ3GEYJ271V	1/16W 270	C44	ECEA0JKS101I	6.3V 100U
R109	ERJ3GEYJ473V	1/16W 47K	R513	ERJ3GEYJ105V	1/16W 1M	C46	ECUV1E223MBN	25V 0.022U
R141	ERJ6GEYJ473V	1/10W 47K	R514	ERJ3GEYJ684V	3W 680K	C51	ECUV1H681KBV	50V 680P
R142	ERJ3GEYJ104V	1/16W 100K	R517	ERJ3GEYJ105V	1/16W 1M	C52	ECUV1C224ZF	16V 0.22U
R151	ERJ3GEYJ152V	3W 1.5K	R519	ERJ3GEYJ563V	3W 56K	C53	ECUV1C104MBM	16V 0.1U
R153	ERJ3GEYJ224V	1/16W 220K	R520-522	ERJ6GEYJ105V	1/10W 1M	C54	ECUV1C105ZFM	16V 1U
R154	ERJ3GEYJ822V	1/16W 8.2K	R523	ERJ3GEYJ105V	1/16W 1M	C55	RCST0GY475LE	4V 4.7U
R156	ERJ3GEYJ184V	3W 180K	R528	ERJ6GEYJ105V	1/10W 1M	C56	ECUV1C105ZFM	16V 1U
R157	ERJ3GEYJ363V	3W 36K	R529	ERJ3GEYJ473V	1/16W 47K	C57	ECUV1E104ZFM	25V 0.1U

Ref. No.	Part No.	Values & Remarks	Ref. No.	Part No.	Values & Remarks			
C58	ECUV1C153MBV	16V 0.015U	C364	ECUV1E103MBV	25V 0.01U			
C59	ECUV1E104ZFM	25V 0.1U	C381	ECUV1H103ZFN	50V 0.01U			
C60	ECUV1C104ZFM	16V 0.1U	C501	ECUV1C104MBM	16V 0.1U			
C61	ECUV1C153MBV	16V 0.015U	C502	ECUV1E473MBN	25V 0.047U			
C62	ECUV1C223MBV	16V 0.022U	C503	ECUV1C104MBM	16V 0.1U			
C101, 102	ECUV1H681KBV	50V 680P	C504	ECUV1C105ZF	16V 1U			
C103	ECEA0GKS470L	4V 47U	C505, 506	ECEA0GKS471I	4V 470U			
C104	ECUV1H472MBV	50V 4700P	C507	ECEA1EKS4R7L	25V 4.7U			
C107	ECUV1C105ZF	16V 1U	C508, 509	ECUV1H100DCV	50V 10P			
C108	ECUV1C333MBN	16V 0.033U	C515	ECUV1E103MBN	25V 0.01U			
C141	ECUV1H681KBV	50V 680P	C516	ECUV1E223MBN	25V 0.022U			
C142	RCST1CY105LE	16V 1U	C517	ECUV1E103MBV	25V 0.01U			
C143	ECUV1C223MBV	16V 0.022U	C518	ECUV1E103MBN	25V 0.01U			
C144	ECEA0JKS220L	6.3V 22U	C519	ECUV1E223MBN	25V 0.022U			
C146	ECEA0GKS221I	4V 220U	C529	RCST0GY475LE	4V 4.7U			
C147	ECEA1EK2R2L	25V 2.2U						
C148	ECUV1E473MBN	25V 0.047U						
C151	ECUV1C334ZF	16V 0.33U						
C152	ECEA1EKS4R7L	25V 4.7U						
C153	ECUV1H272KBN	50V 2700P						
C154	ECUV1C474ZFM	16V 0.47U						
C155	ECUV1C154KR	16V 0.15U						
C156	ECUV1C333MBN	16V 0.033U						
C157, 158	ECUV1H472MBV	50V 4700P						
C171	ECEA0GKS221I	4V 220U						
C172	ECEA0GKS470L	4V 47U						
C201, 202	ECUV1H681KBV	50V 680P						
C203	ECEA0GKS470L	4V 47U						
C204	ECUV1H472MBV	50V 4700P						
C207	ECUV1C105ZF	16V 1U						
C208	ECUV1C333MBN	16V 0.033U						
C251	ECUV1C334ZF	16V 0.33U						
C252	ECEA1EKS4R7L	25V 4.7U						
C253	ECUV1H272KBN	50V 2700P						
C254	ECUV1C474ZFM	16V 0.47U						
C255	ECUV1C154KR	16V 0.15U						
C256	ECUV1C333MBN	16V 0.033U						
C257, 258	ECUV1H472MBV	50V 4700P						
C301-303	ECUV1E104MBM	25V 0.1U						
C304	ECEA1HKS010L	50V 1U						
C305, 306	RCST1CY105LE	16V 1U						
C307	ECEA1HKS010L	50V 1U						
C351	ECEA0JKS101I	6.3V 100U						
C352	ECUV1C105ZF	16V 1U						
C353	ECUV1H150KCV	50V 15P						
C354	ECUV1H821KN	50V 820P						
C355	ECUV1C104MBM	16V 0.1U						
C357	ECUV1C105ZF	16V 1U						
C360	ECUV1E103MBV	25V 0.01U						
C361	ECUV1H040CCV	50V 4P						
C362	RCST1CY105LE	16V 1U						
C363	ECUV1E223MBN	25V 0.022U						